

SECTION 4
NORMAL PROCEDURES

These procedures complete those of standard airplane described in Section 4 "Normal procedures" of the basic Flight Manual.

NOTE :

*Checks marked * may be omitted if the flight will not be into known icing conditions.*

PREFLIGHT INSPECTIONS

COCKPIT

1 - Switches

Prime and / or inspect prior to flight :

"ANTI-ICE" / "DE-ICE" * On "ANTI-ICE" or "DE-ICE"
Wing inspection light "ON"

AIRFRAME INSPECTION

2 - Fluid tank

Quantity * Checked
(Mini. indicated : 1.7 U.S Gallons - 6.4 l)
Filler cap SECURE
Filler door CLOSED
Drain Check closed and not leaking

3 - Porous panels

Condition and security Checked
Evidence of fluid flow * From all panels checked
Wing inspection light "ON" checked

SWITCHES

All "OFF"